

## INTRODUCING



## BUILD WITH CONFIDENCE





## Specification:

Seat/Back

- Plastic injection moulded seat and back with good textured finish and Good balance of stiffness & impact resistance incorporated virgin material

Armrest/Legs - Plastic Injection moulded with textured finish high rigidity polyamide material to bear the desirable loads

Centrebeam

- MS square tube of 1.6mm thickness Processed & furnished with powder coating.












# VIVA MULTI SEATER PLASTIC SOFA DIMENSIONS







VIVA MULTISEATER - 1 SEATER WEIGHT - 10.82 KG

VIVA MULTISEATER - 2 SEATER WEIGHT - 16.88 KG






VIVA MULTISEATER - 3 SEATER WEIGHT - 23.72 KG



VIVA MULTISEATER - 4 SEATER WEIGHT - 30.72 KG



VIVA MULTISEATER - 6 SEATER WEIGHT - 43.37 KG





### **TEMPERATURE RESISTANCE**



AVAILABLE FOR OUTDOOR APPLICATION ALSO (CHARGES MAY VARY FOR UV PROTECTOR)



RUST PROOF (SEAT, BACK, ARMS & LEGS)



**EASY TO INSTALL** 



ANTI - STATIC



**WASHABLE** 



**DURABLE** 



**RECYCLABLE** 




MADE IN INDIA




VIVA MULTI SEATER PLASTIC SOFA 3 SEATER ASSEMBLY INSTRUCTION




VIVA MULTI SEATER CHILD PARTS & ACCESSORIES




### **VIVA MULTI SEATER 3S ASSEMBLY**













#### VIVA MULTI SEATER 3S ASSEMBLY





#### STEP 1A:

- 1. Place the leg assembly on the extreme ends of centerbeam.
- 2. Place the center beam assembly above the legs.
- 3. Place the handle above the leg use Flat head M8 x 135mm bolt in loose condition.
- 4. Place the handle above centerbeam & use the handle holder to clamp the inbetween handles & use M8 x 65mm bolt in loose condition.

STEP 1B: Place the seat between the handle & use M8 x 35mm bolt to tighten the seat to the handle ( for required quantity).

STEP 1C: Place the back between the handle & use M8 x 35mm bolt to tighten the back to the handle (for required quantity).

After done required alignments should tighten the all bolts.

STEP 2A: Place the insert cap to the handle insert outside area and ensure them inserts hide from the handle.

STEP 2B: Assemble the leveller in the legs & adjust as per your requirement.

STEP 2C: Ensure the all bolts to be tighten & see the appearance if everything is perfect now Axis multiseater is ready to use.



## **ADDRESS:**

NO: 36/4, BALFOUR ROAD, KILPAUK, CHENNAI-10
PH.NO: +91 98417 98417 | WEBSITE: WWW.MBMINDIA.CO.IN
E-MAIL: SALES@MBMINDIA.CO.IN

### **BANGALORE BRANCH**

NO,275/8, NEW TIMBER YARD LAYOUT, INSIDE NAK KALYANA MANDAPPAM, MYSORE ROAD, BANGALORE - 560026. +91 94480 51246 / +91 94480 53689 / +91 95386 77428

#### **HYDERABAD BRANCH**

CENTRAL WAREHOUSING CORPORATION, GODOWN NO. B-3, BEHIND - GANDHI BHAVAN, NAMPALLY, HYDERABAD - 500001. +91 8500 364 068 / +91 8500 274 068

#### MUMBAI

SHOP NO. A/4, FIRST FLOOR, MAHAVIR ESTATE, SAKINAKA, ANDHERI GHATKOPAR LINK ROAD, BEHIND TILAK NAGAR GATE, SAKINAKA, MUMBAI-400072. PH:-+91 9004472306

#### **DELHI BRANCH**

KHASRA NO. 51/6, VILLAGE ALIPUR, LANDMARK SPLASH WATER PARK, DELHI - 110036. +91 93126 72007 / +91 82876 04060